Mr./Mrs/Ms:					Mod	del:				Reg.No:		
Invoice/Job no:				Odo	Odometer reading:						V.I.N:	
Service type:		FS	LS	Α	В	Α	В	Α	В	Α	В	
Months/,000 miles:		6		12	24	36	48	60	72	84	96	
Adjust/Lubricate/Replace - Labour cost included in scheduled time except items marked *												

Check - After the checking procedure, cleaning, adjusting, repairing or replacing is subject to extra labour and material cost.



ROVER 100 AND METRO (XP)

(ALL MODELS)

MAINTENANCE CHECK SHEET

			PRELIMINARY
1.			Before commencing work, check for any outstanding service actions.
	FS		FIRST SERVICE
2.	6k		Replace engine oil and filter - First 6000 miles only - Diesel only
	LS		LUBRICATION SERVICE
3.			Replace engine oil and filter- Diesel only
٥.	Α	В	MAIN SERVICE
_			Annual corrosion/cosmetic inspection - Using annual corrosion inspection sheet
4. 5.	\vdash		Replace engine oil and filter
6.		Ħ	Replace automatic gearbox oil
7.			Replace antifreeze - 36k and then every 24k
8.	\Box		Check battery connections and antifreeze
9.	Ħ	一	Check brake, PAS, clutch & gearbox fluid levels
10.		$\overline{}$	Check pressure sensing hoses and vacuum pipes
11.	60k	120k	Replace camshaft drive belt- Petrol
12.		72k	Replace camshaft belt- Diesel
13.			Lubricate carburetter piston damper
14.			Check cooling system hoses and connections for signs of leakage and condition
15.			Check fuel & clutch pipes and hoses for signs of leakage and condition
16.			Check condition of crankcase vent hoses & valves where fitted
17.			Check air conditioning system, hoses and sight glass
18.			Check auxiliary drive belts tension and condition
19.			Replace air cleaner element
20.			Replace fuel filter - Diesel
21.		48k	Replace fuel filter - Petrol
22.			Replace spark plugs
23.			Replace brake fluid - Every 24 months regardless of mileage*(indicate replacement on service record)
24.			Check exhaust system and heat shields
25.			Remove front road wheels
26.			Check front brake linings, disc, calipers, hoses and pipes
27.			Remove rear road wheels
28.			Check rear brake linings, drums, cylinders, hoses and pipes
29.			Check road wheels
30.			Check suspension and steering for signs of leaking or wear
31.	\square		Check wheel bearings, drive shafts and gaiters
32.	Щ		Adjust handbrake - First 12,000 miles only
33.	Щ	Щ	Grease suspension pivots, ball joints, handbrake clevis pins and quadrants
34.		\square	Check handbrake operation

А В	MAIN SERVICE	
35	Check seatbelt and airbag module cover. Check tyre pressures, condition and trea	I.N- 36 months and then every 12 months s - 36 months and then every 12 months d depth (mm) LHR Spare
9.	Check lamps, horns, and system warning Check screen wipers and washers Replace alarm handset batteries	indicators
1	10 YEAR REPLACEMENT - AIRBAGS	
42.	Replace airbag module* AFTER EACH MAIN SERVICE	
43.		then every 12 months. (Record CO%) t 36 months and then every 12 months. chicles only odels only
		ng under normal driving, road and climatic conditions. Mo ration, extremes of temperature, dusty conditions or freque
Service check completed	d, cosmetic/corrosion inspection check completed and s	ervice portfolio book stamped
lame:	Signature:	Date: